



Linear motor actuator

E-RAM Series

DA30 Driver User Manual

Ver1.0

Thank you for purchasing our linear motor actuator.

This user manual is a supplement to the manufacturer's catalog, and its purpose is to provide users with more detailed and convenient usage instructions. We have attempted to ensure the accuracy and completeness of the content. Nevertheless, we recommend that users use the manufacturer's catalog as a guide.

Please take the time to read this manual carefully before use. Please keep it in a safe place so that you can view it whenever necessary.

List

One.Driver Overview	5
1.1 Manufacturer Information	5
1.2 Safety precautions	5
2. final	6
2.1 Main circuit.....	6
2.2 Control circuit	6
□ C2 interface	6
□ C3 interface	7
3. Debugging.....	8
3.1 Software download and installation.....	8
□ software download.....	8
□ Software installation	8
3.2 Language settings	9
3.3 Communication between computer and driver	9
□ final.....	9
□ communication.....	10
3.4Importing motor parameters	10
□ Download parameter pack.....	10
□ Importing parameter packs	10
□ motor inspection.....	14
3.5 Commissioning	15
□ Automatic correction	15
□ Inching preparation.....	18
□ Waveform acquisition	19
□ Settlement time analysis.....	
□ Fine adjustment of rigidity	
□ Check debugging results	21

3.6 Control	22
<input type="checkbox"/> Select mode	22
<input type="checkbox"/> Pulse mode settings	22
<input type="checkbox"/> Electronic gear ratio settings.....	22
<input type="checkbox"/> I/O settings	23
<input type="checkbox"/> Change of driving direction	23
<input type="checkbox"/> Power-on activation settings	25
3.7 Parameter backup & parameter recovery	26
<input type="checkbox"/> Parameter backup	26
<input type="checkbox"/> Parameter recovery	27

1. Driver Overview

1.1 Manufacturer Information

Driver manufacturer: Servotronix

Manufacturer's official website: <https://www.servotronix.cn/en>

The manufacturer model number table is as follows.

Misumi model number	Servotronix model number
DA30	CDHD-0032AAP1

1.2 Safety precautions


Before installation, please be sure to download and read all relevant materials from the manufacturer's website carefully, and use and operate the product exactly as required to ensure safety and accuracy.

Please use caution as improper handling may result in personal injury and/or equipment damage.

2. final


2.1 Main circuit

Driver rated input current 3A, maximum current 9A




2.2 Control circuit

● C2 interface



● C3 interface



3. Debugging

3.1 Software download and installation

● software download


Download from the manufacturer's website.

Download link: <http://m.servotronix.com.cn/col.jsp?id=197>


All software versions ServoStudioSetup_2_38_6_20 and higher are available.



● Software installation

 ServoStudioSetup_2_38_6_20.exe Double-click to complete the installation,

 ServoStudio.exe Double click to open the software and you are ready to use it.




3.2 Language settings

① Click <Preferences>, and ② you can change it to <ENG> or <CHS>. If you want to change the language, select the language you want to change, and click ③<Set Language>.

If you close the program and turn it back on, it will change to the set language.

! When selecting a language, CHS represents Chinese and ENG represents English.



3.3 Communication between computer and driver

● final

Connect the computer to driver①<C1 port> with a communication cable, then turn on the driver.

! Before turning on the power, be sure to check that all wiring is correct.




● communication

1 If communication is successful by clicking <Communication> and clicking ②<Connect>,

③<Disconnected> will appear.  Online changes to .

! If communication is not possible, reconnect the communication cable, reboot the computer, turn the driver power back on, and replace the communication cable.




3.4 Importing motor parameters

● Download parameter pack

You can download the parameter pack from the MISUMI website or request it from MISUMI customer service staff.

Select the parameter pack according to the model number of the actuator you purchased.


Example) If the model number of the linear motor actuator is E-RAM6-S-280-DA30-C3, the corresponding parameter pack is E-RAM6-S-DA30.



● Importing parameter packs

Operate in the following order:


- 1 Click <Backup & Restore>.
- 2 Click <Recover from file to driver>.




- 3 Double-click the locally saved parameter pack.

<input type="checkbox"/>	이름	수정한 날짜	유형	크기
<input type="checkbox"/>	E-RAM6-S-DA30.ssv	2024-02-29 오후 6:42	SSV 파일	14KB


- 4 Click <OK>.



5 Click <All>.




6 Click <Save>, and click ⑦<Save to Driver>.



Power off the driver, wait 5 seconds, and then power it back on to allow the computer to communicate with the driver.

Click ⑧<Motor>, click ⑨<Read from Driver>, check ⑩<Motor Information> to determine whether the parameters have been imported correctly, click ⑪<Save>, and click ⑫<Save as Driver>. do.




● motor inspection

First, push the slider on the actuator to the middle position.




- 1 Click <Motor>.
- 2 Click <Inspect>.

1




- 3 If you click <OK>, the actuator will move slightly and the inspection will be completed.




3.5 Commissioning

● auto tuning

- 1 Click <Auto Tuning>.
- 2 Click <Start Load Estimation>.




- 3 Click <OK>, and click ④<Next>.




Depending on the actual usage situation, set ⑤<distance (encoder unit)>, ⑥<speed>, and ⑦<acceleration>,
Click ⑧<Start Debugging> to allow the actuator to continue operating for a few minutes. When the settings are complete, click ⑨<Next>.


! Distance unit 1=1μm, acceleration unit 10000=1G



⑩Click <Save>.



Click ⑪<SAVE>, and click ⑫<Complete>.



● Preparing for commissioning

Click ①<Scope> and set ② to <Serial Position>.

③Set <Position>, <Velocity>, <Acc>, and <Dec>.

④Change the name in <Trigger Setup> to <V>, ⑤Change <Level> to <10>, ⑥Change <Pre-Points> to <10>.

⑦Select the variables to record in <Record Variables>.

! Whenever you change parameters, be sure to save them to prevent them from being lost due to external factors such as power outage.

! Position unit: 1counts=1 μ m Example) To move 10mm, enter 10000 counts.


! Common variables include:

PTPVCMD position command speed


PE position error


ICMD current command

V actual speed




● Waveform acquisition

1  When you click , the button changes to <Start> and then the driver is activated.

②  When you click , the actuator starts operating, and when operation is completed, ③<Waveform display> is displayed.


! It is normal for the actuator to emit an electromagnetic sound after activation.

! When you are finished driving, be sure to turn it off for safety reasons.



● Settling Time Analysis

Place the mouse at a random location on the oscillogram, right-click, and select ①<Show Settling Time>.



- ① Set <PVPVCMD> in <Command>, and select <PE> in ②<Response>.
- ③Set the position accuracy error (unit μm) in <Acceptable Range>, and click ④<Show>.
- ⑤The required settling time is displayed in <Setting Time>.

Example) If Acceptable Range is set to 5 and Setting Time is displayed as 95, it indicates that the position accuracy error is within $5\mu\text{m}$ and the required settling time is 0.095 seconds.



● Gain Tuning

In principle, debugging can be completed through <Auto Tuning>, and the stiffness can be fine-tuned to bring the actuator to the best condition.

! Debugging tips:

By adjusting the stiffness level, you can increase the responsiveness of the actuator or suppress module vibration and noise.

- 1 Click <Tuning> to set ②<Gain Level>.



● Check debugging results

After collecting the waveform again, the settling time is analyzed.

Example) After increasing the rigidity level, the positioning accuracy error is within 5 μm , and the required correction time has been changed from 0.095 seconds to 0 seconds.




3.6 Control

● mode select

1 Click <Drive Information> and select ②<Interface Mode> as <Serial/Pulse>.

! For commissioning, change to <Serial/Pulse>.




● Pulse mode settings

Click ①<Work Mode>, select ②<Electrical Device/Pulse Train>, and check ③<Electrical Enabled>.

Select ④<Pulse Train Source> (differential pulse or single-ended pulse) according to the host computer,

4 Select <Pulse Train Type>.




● Electronic gear ratio settings

①Click <Motion>, and set ②<Feed Constant Scaling Numerator>

Formula: Actual travel distance = command pulse x (electronic gear numerator/electronic gear denominator) x 0.001mm


! Be sure to press the Enter key after setting the parameters.



● I/O settings

Click ①<Digital I/O> to set ②<Mode> and ③<Polarity>.

! Polarity <High level valid> is NPN mode.



● Change direction of travel

① Click <Tuning>, enter dir in ②<Terminal>, then press Enter to check ③<Result>.

③If <Result> is 0, enter dir 1 in ②<Terminal>.

③If <Result> is 1, enter dir 0 in ②<Terminal>.

②Enter mphase in <Teminal>, then press the Enter key to check ④<Result>.

④If <result> is less than 180, add 180 to this result,

④If <result> is greater than or equal to 180, subtract 180 from this result.

Example) If ④<result> is 0, enter mphase 180 in ②<dialog window>.


④If <result> is 210, enter mphase 30 in ②<dialog window>.

5 Click <config>.

6

! Type dir or mphase, followed by a space, then 3 or 0 or some other number. Otherwise, an error will occur.


! These two variables, dir and mphase, must be changed at the same time. Otherwise, motor runaway will occur.



● Power-on activation settings


① Click <Activation and Troubleshooting> and check ② <Automatically Activate after Power On>.

! If you do not control the driver's operation with a higher-level computer, remove <Automatic activation after power on> and set <Remote activation> in ② <Mode> in <Digital I/O> to Idle. Otherwise it cannot be activated.




! When in differential pulse mode, the driver checks the level status of the differential pulse, and when the pulse line is not connected, the driver sounds the R25 alarm. The operation method to block the alarm is as follows.

③ Click <Terminal>, enter IGNOREPDLB 2 in ④ and press the Enter key.



! When the pulse train type is CW/CCW pulse mode, the driver's inability to receive pulses can be resolved as follows:

Enter APINLOGIC 0 (or 1) in ④ and press the Enter key.




3.7 Parameter backup & parameter recovery


● Parameter backup

Click ①<Backup & Recovery>, click ②<Save>, then click ③<Save to Driver>.

④Click <Save to backup file>.



Enter the file name in ⑤ and click ⑥<Save>.



● Parameter recovery

For recovery method, please refer to <3.4 Importing Motor Parameters>.

The differences are as follows:

1. The parameter pack is changed to the saved parameter pack.
2. No need to do motor inspection.